

Switch

- Initial config on ex switches

Initial config on ex switches

TR

Aşağıda daha önce uygulanmış üzerinde vlanleri açık ve aggregated interfaceleri ekli örnek bulabilirsiniz. kopyalarken ilk satırı dışarıda bırakmayı unutmayınız.

EN

You can find a initial configuration tested on field.

```
root@some_customer-BACKBONE# show | display set | no-more
set version 13.2X51-D35.3
set system host-name some_customer-BACKBONE
set system auto-snapshot
set system time-zone Europe/Istanbul
set system name-server 10.123.123.123
set system name-server 10.123.123.123
set system services ssh protocol-version v2
set system services telnet
set system services netconf ssh
set system services web-management http
set system syslog user * any emergency
set system syslog file messages any notice
set system syslog file messages authorization info
set system syslog file interactive-commands interactive-commands any
set system ntp
set chassis redundancy graceful-switchover
set chassis aggregated-devices ethernet device-count 30
set chassis alarm management-ethernet link-down ignore
set interfaces interface-range all-ports member-range ge-0/0/0 to ge-0/0/31
set interfaces interface-range all-ports member-range ge-1/0/0 to ge-1/0/31
set interfaces interface-range all-ports member-range ge-2/0/0 to ge-2/0/31
set interfaces interface-range all-ports member-range xe-1/0/0 to xe-1/0/31
set interfaces interface-range all-ports member-range xe-0/0/0 to xe-0/0/31
```

```
set interfaces interface-range all-ports member-range xe-2/0/0 to xe-2/0/31
set interfaces ge-0/0/0 ether-options 802.3ad ae13
set interfaces ge-0/0/1 ether-options 802.3ad ae14
set interfaces ge-0/0/2 ether-options 802.3ad ae16
set interfaces ge-0/0/3 ether-options 802.3ad ae18
set interfaces ge-0/0/4 ether-options 802.3ad ae19
set interfaces ge-0/0/5 ether-options 802.3ad ae21
set interfaces ge-0/0/6 ether-options 802.3ad ae23
set interfaces ge-0/0/7 ether-options 802.3ad ae24
set interfaces ge-0/0/8 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/8 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/9 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/9 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/10 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/10 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/11 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/11 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/12 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/12 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/13 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/13 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/14 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/14 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/15 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/15 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/16 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/16 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/17 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/17 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/18 ether-options 802.3ad ae25
set interfaces ge-0/0/19 ether-options 802.3ad ae25
set interfaces ge-0/0/20 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/20 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/21 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/21 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/22 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/22 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/23 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/23 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/0/24 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/0/24 unit 0 family ethernet-switching storm-control default
```

[illegible]

```
set interfaces xe-0/2/2 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/2/3 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/2/3 unit 0 family ethernet-switching storm-control default
set interfaces xe-0/2/3 unit 0 family ethernet-switching vlan members default
set interfaces xe-0/2/3 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/2/4 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/2/4 unit 0 family ethernet-switching storm-control default
set interfaces xe-0/2/4 unit 0 family ethernet-switching vlan members default
set interfaces xe-0/2/4 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/2/5 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/2/5 unit 0 family ethernet-switching storm-control default
set interfaces xe-0/2/5 unit 0 family ethernet-switching vlan members default
set interfaces xe-0/2/5 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/2/6 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/2/6 unit 0 family ethernet-switching storm-control default
set interfaces xe-0/2/6 unit 0 family ethernet-switching vlan members default
set interfaces xe-0/2/6 unit 0 family ethernet-switching storm-control default
set interfaces ge-0/2/7 unit 0 family ethernet-switching vlan members default
set interfaces ge-0/2/7 unit 0 family ethernet-switching storm-control default
set interfaces xe-0/2/7 unit 0 family ethernet-switching vlan members default
set interfaces xe-0/2/7 unit 0 family ethernet-switching storm-control default
set interfaces ge-1/0/0 ether-options 802.3ad ae13
set interfaces ge-1/0/1 ether-options 802.3ad ae15
set interfaces ge-1/0/2 ether-options 802.3ad ae17
set interfaces ge-1/0/3 ether-options 802.3ad ae18
set interfaces ge-1/0/4 ether-options 802.3ad ae20
set interfaces ge-1/0/5 ether-options 802.3ad ae21
set interfaces ge-1/0/6 ether-options 802.3ad ae22
set interfaces ge-1/0/18 ether-options 802.3ad ae25
set interfaces ge-1/0/19 ether-options 802.3ad ae25
set interfaces ge-1/0/29 ether-options 802.3ad ae3
set interfaces ge-1/0/30 ether-options 802.3ad ae1
set interfaces ge-1/0/31 ether-options 802.3ad ae2
set interfaces ge-2/0/0 ether-options 802.3ad ae14
set interfaces ge-2/0/1 ether-options 802.3ad ae15
set interfaces ge-2/0/2 ether-options 802.3ad ae17
set interfaces ge-2/0/3 ether-options 802.3ad ae20
set interfaces ge-2/0/4 ether-options 802.3ad ae19
set interfaces ge-2/0/5 ether-options 802.3ad ae22
set interfaces ge-2/0/6 ether-options 802.3ad ae23
set interfaces ge-2/0/18 ether-options 802.3ad ae25
```

```
set interfaces ge-2/0/19 ether-options 802.3ad ae25
set interfaces ge-2/0/29 ether-options 802.3ad ae4
set interfaces ge-2/0/30 ether-options 802.3ad ae1
set interfaces ge-2/0/31 ether-options 802.3ad ae2
set interfaces ae1 description to-FIREWALL-1
set interfaces ae1 aggregated-ether-options lacp active
set interfaces ae1 aggregated-ether-options lacp periodic fast
set interfaces ae1 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae1 unit 0 family ethernet-switching vlan members all
set interfaces ae2 description to-FIREWALL-2
set interfaces ae2 aggregated-ether-options lacp active
set interfaces ae2 aggregated-ether-options lacp periodic fast
set interfaces ae2 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae2 unit 0 family ethernet-switching vlan members all
set interfaces ae3 description to-ARUBA-1
set interfaces ae3 aggregated-ether-options lacp active
set interfaces ae3 aggregated-ether-options lacp periodic fast
set interfaces ae3 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae3 unit 0 family ethernet-switching vlan members all
set interfaces ae4 description to-ARUBA-2
set interfaces ae4 aggregated-ether-options lacp active
set interfaces ae4 aggregated-ether-options lacp periodic fast
set interfaces ae4 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae4 unit 0 family ethernet-switching vlan members all
set interfaces ae13 description to-BK-KB3-VC1
set interfaces ae13 aggregated-ether-options lacp active
set interfaces ae13 aggregated-ether-options lacp periodic fast
set interfaces ae13 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae13 unit 0 family ethernet-switching vlan members all
set interfaces ae14 description to-BK-KB3-VC2
set interfaces ae14 aggregated-ether-options lacp active
set interfaces ae14 aggregated-ether-options lacp periodic fast
set interfaces ae14 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae14 unit 0 family ethernet-switching vlan members all
set interfaces ae15 description to-BK-KB4-VC1
set interfaces ae15 aggregated-ether-options lacp active
set interfaces ae15 aggregated-ether-options lacp periodic fast
set interfaces ae15 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae15 unit 0 family ethernet-switching vlan members all
set interfaces ae16 description to-BK-KB4-VC2
set interfaces ae16 aggregated-ether-options lacp active
```

```
set interfaces ae16 aggregated-ether-options lacp periodic fast
set interfaces ae16 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae16 unit 0 family ethernet-switching vlan members all
set interfaces ae17 description to-BK-KB5-VC1
set interfaces ae17 aggregated-ether-options lacp active
set interfaces ae17 aggregated-ether-options lacp periodic fast
set interfaces ae17 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae17 unit 0 family ethernet-switching vlan members all
set interfaces ae18 description to-BK-KB6-VC1
set interfaces ae18 aggregated-ether-options lacp active
set interfaces ae18 aggregated-ether-options lacp periodic fast
set interfaces ae18 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae18 unit 0 family ethernet-switching vlan members all
set interfaces ae19 description to-MZ-K5-VC1
set interfaces ae19 aggregated-ether-options lacp active
set interfaces ae19 aggregated-ether-options lacp periodic fast
set interfaces ae19 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae19 unit 0 family ethernet-switching vlan members all
set interfaces ae20 description to-MZ-K4-VC1
set interfaces ae20 aggregated-ether-options lacp active
set interfaces ae20 aggregated-ether-options lacp periodic fast
set interfaces ae20 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae20 unit 0 family ethernet-switching vlan members all
set interfaces ae21 description to-BK-KB1-VC1
set interfaces ae21 aggregated-ether-options lacp active
set interfaces ae21 aggregated-ether-options lacp periodic fast
set interfaces ae21 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae21 unit 0 family ethernet-switching vlan members all
set interfaces ae22 description to-BK-KB2-VC1
set interfaces ae22 aggregated-ether-options lacp active
set interfaces ae22 aggregated-ether-options lacp periodic fast
set interfaces ae22 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae22 unit 0 family ethernet-switching vlan members all
set interfaces ae23 description to-BK-KB2-VC2
set interfaces ae23 aggregated-ether-options lacp active
set interfaces ae23 aggregated-ether-options lacp periodic fast
set interfaces ae23 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae23 unit 0 family ethernet-switching vlan members all
set interfaces ae24 description to-BK-KB1-VC2
set interfaces ae24 aggregated-ether-options lacp active
set interfaces ae24 aggregated-ether-options lacp periodic fast
```

```
set interfaces ae24 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae24 unit 0 family ethernet-switching vlan members all
set interfaces ae25 description to-SYS-VC1
set interfaces ae25 aggregated-ether-options lacp active
set interfaces ae25 aggregated-ether-options lacp periodic fast
set interfaces ae25 unit 0 family ethernet-switching interface-mode trunk
set interfaces ae25 unit 0 family ethernet-switching vlan members all
set interfaces irb unit 0 family inet
set interfaces irb unit 10 family inet address 10.123.11.200/23
set interfaces vme unit 0 family inet address 10.0.0.200/24
set snmp location "some_customer, GEBZE"
set forwarding-options storm-control-profiles default all
set routing-options static route 0.0.0.0/0 next-hop 10.123.11.254
set protocols lldp interface all
set protocols lldp-med interface all
set protocols igmp-snooping vlan default
set protocols igmp-snooping vlan all
set protocols layer2-control nonstop-bridging
set vlans AP vlan-id 20
set vlans ARM vlan-id 333
set vlans Cargo vlan-id 105
set vlans Barcode vlan-id 85
set vlans Guest vlan-id 210
set vlans INTERNET-SOL vlan-id 434
set vlans INTERNET-VF vlan-id 433
set vlans Konveyor vlan-id 230
set vlans Management vlan-id 10
set vlans Management I3-interface irb.10
set vlans Mng vlan-id 107
set vlans Other vlan-id 90
set vlans Other2 vlan-id 95
set vlans Pdks vlan-id 220
set vlans Printer vlan-id 80
set vlans RF vlan-id 70
set vlans RF2 vlan-id 75
set vlans SERVER vlan-id 40
set vlans Scada vlan-id 97
set vlans Thinclient vlan-id 60
set vlans Thinclient2 vlan-id 65
set vlans SomeCustomerSecure vlan-id 110
set vlans SomeCustomerSecure2 vlan-id 115
```

```
set vlans User vlan-id 50
set vlans User2 vlan-id 55
set vlans VO-IP vlan-id 30
set vlans Video vlan-id 96
set vlans Cargo2 vlan-id 106
set vlans default vlan-id 1
set vlans default I3-interface irb.0
```